





# **Fabrication and Prototyping in the LearningLab ProtoFabStats**

Adriana Moisil

# Overview

1. Motivation
2. Hardware
3. Methodology
4. Demo
5. Conclusions & Future Work






# Motivation




# Motivation - I/2


- record information about changes in
  - number of occupants
  - status of the door
    - locked/unlocked
    - open/closed
- graphic visualization



# Motivation - 2/2

- compute statistics about the space usage
  - average number of users
    - per day
    - per hour
  - busiest day in the past 7 days






# Hardware




# Adafruit ESP32-S3 Feather

- connected to distance & gesture sensors
- publishes measurements using MQTT



# Time of Flight Distance Sensor


- Adafruit VL53L4CX
- 0 mm up to 6 m
- multi-object detection
  - keep only the closest one
- replacement for VL53L0X
  - which most of the times was not working





# Proximity, Light, RGB, and Gesture


- Adafruit APDS9960
- direction of movement
  - up
  - down
  - left
  - right



# Raspberry Pi Zero

- acts as server
- subscribes to all MQTT topics
- can be accessed by anyone on the network






# Methodology




# Components Overview




# ESP 32

- ESP32 subscribed to MQTT topics
  - door/event/open\_closed
  - door/event/locked\_unlocked
- status of the door is known => read data less often if we have an indication that the door is not open
  - every 50ms when door is open
  - every 0.1 seconds when door is unlocked but closed
  - every second when door is locked




# Raspberry Pi

- 4 Linux Services
  - Grafana
  - Preprocessing Service
  - Days of Week Stats Service
  - Hour Stats Service
- Docker Container
  - Mosquitto
  - Telegraf
  - InfluxDB V1
  - Flask Service




# Grafana

- live data for
  - locked/unlocked
  - closed/open
  - esp32/APDS9960
    - enter/leave
  - esp32/VL53L4CX
    - distance to closest target within range
- no live data for average occupancy/occupancy per week



# Data Processing Service - I/2


- updates InfluxDB measurement APDS9960\_processed every 10 minutes
- computes occupancy metric based on enter/leave events
  - when does the number of people change?





# Data Processing Service - 2/2


- validates data
  - based on certain assumptions
    - room is accessed only when the building is open (e.g. 7:00 – 22:00)
    - nobody is there at midnight
    - adds dummy data at midnight if  $\text{events}(\text{enter}) \neq \text{events}(\text{leave})$ 
      - missing/wrong data
      - signal these findings



# APDS9960




APDS9960 - Max Occupancy last 7 days






# Day of Week Stats Service

- updates InfluxDB measurement APDS9960\_days\_of\_week
- computes average occupancy metric based on weekdays
  - removes everything else => never more than one value / weekday
- intended to run daily at 4:00
  - for testing, runs every 5 mins




APDS9960 - Days of Week Average




# Hour Stats Service

- updates InfluxDB measurement APDS9960\_hour
- computed for the last 7 days
- computes average occupancy metric based on hour
- intended to run every hour
  - for testing, runs every 5 mins



APDS9960 - Hours Average ▾



APDS9960\_hour.average



# Flask Service - 1/2

- anyone with university email can request access

## Please register

Only domains "students.unibe.ch", "unifr.ch", "unine.ch" are accepted.

**Request Access**


Already have access? [Login now](#)

# Flask Service - 2/2

- access can be granted/revoked by admins

## Requests Manager

#	Email	Admin	Enabled
1	admin	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	admin@unifr.ch	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	dummy_user_0@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>
4	dummy_user_1@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	dummy_user_2@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>
6	dummy_user_3@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>
7	dummy_user_4@unifr.ch	<input type="checkbox"/>	<input type="checkbox"/>
8	dummy_user_5@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>
9	dummy_user_6@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>
10	dummy_user_7@unifr.ch	<input type="checkbox"/>	<input type="checkbox"/>
11	dummy_user_8@unifr.ch	<input type="checkbox"/>	<input type="checkbox"/>
12	dummy_user_9@unifr.ch	<input type="checkbox"/>	<input checked="" type="checkbox"/>




# Experiment Setup



# Setup

APDS9960


VL53L4CX



# Setup

APDS9960



VL53L4CX



# Setup

APDS9960

VL53L4CX



```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

990

1000

991

1002

991

1002

992

1003

992

1003

992

1003

991

1002



```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

990

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

1000

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

991

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

1002

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

991

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

1002

```
=====
VL53L4CX: :ReadAndPrintMeasurement:  objects found.
```

992

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found
```

1003

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

992

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

1003

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

992

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

1003

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```

991

```
=====
VL53L4CX::ReadAndPrintMeasurement: 1 objects found.
```


1002

# THRESHOLD:




# APDS9960 Testing


- 20 times entering/leaving the room => 40 recordings
- Test 1
  - Start time 23:15
  - End time 23:18
  - 32 recorded (80%)
- Test 2
  - Start time 23:31
  - End time 23:34
  - 34 recorded (85%)



APDS9960 - enter/leave + occupancy




APDS9960 - enter/leave + occupancy




# VL53L4CX Testing


- 



# Data Generation

- need data for multiple days to test statistics
  - 21 days
  - 0–30 events/day
  - 80% of days are valid
    - `events(enter) == events(leave)`
    - `sum(events(enter)) >= sum(events(leave))` at any given point





# Demo






# **Conclusions & Future Work**



# Conclusions


- working with sensors (and various pieces of hardware in general) can be tricky






# Future Work

- connect with the other 2 projects
- look into using alerts in Grafana
- send confirmation email when permission is requested/granted





**Thank you!**




# Appendix





# **Grafana - Door Events**



Open/Closed ▾

CLOSED

2

2

2

2

2

1

1

1

1

OPEN

1

1

1

1

1

0

0

0

0

UNKNOWN

11/12/2023 22:21:34

12/12/2023 21:13:38

12/12/2023 21:28:38

13/12/2023 19:50:00

open\_closed.status

# Door Events

locked\_unlocked.status


LOCKED

open\_closed.status

OPENUNKNOWN


20:00 21:00 22:00 23:00 00:00 01:00 02:00 03:00 04:00 05:00 06:00 07:00 08:00 09:00 10:00 11:00 12:00 13:00 14:00 15:00 16:00 17:00 18:00 19:00

LOCKED UNLOCKED CLOSED OPEN UNKNOWN



# Analysing the Data

- event = person entering/leaving
- define minimum duration of event
  - 1ms
- define minimum interval between two different events
  - 1ms
- create groups of measurements





# Analysing the Data

